

Vermiculite must cover the bottom and top of the packing spaces.

Web site: www.airseadg.com E-mail: uk@airseadg.com

ASSEMBLY DETAILS: